



Schematic diagram of AIWA TV-1402, TV-2002, TV-2102 CTV





- 1)PROG - 5)PICTURE
- 2)PROG + 6)AV
- 3)VDL - 7)NICAM
- 4)VDL + 8)STANDBY OFF

S009 SERVICE MODE

Photo DET.

IR. PreAMP.

EEPROM


Regulator with reset

Error amplifier

Power regulator

VOLTAGE

PWR ON / STANDBY



Power regulator

VOLTAGE

PWR ON

STANDBY

Regulator with reset

EEPROM

