

# FRONT PWB

DISPLAY

DSP201


BJ180GK

DIODE OPTION


1 : W/DIODES 0 : W/O DIODES

| NAME | PIN | FUNCTION       | OPTION |                |   |                |   |                |   |                |
|------|-----|----------------|--------|----------------|---|----------------|---|----------------|---|----------------|
| D208 | 49  | AREA           | 0      | KOREA          | 1 | USA            | 0 | EUROPE         | 1 | JAPAN          |
| D209 | 50  |                |        |                |   |                |   |                |   |                |
| D210 | 51  | FM STEP        | 0      | FM 100kHz STEP | 1 | FM 50kHz STEP  |   |                |   |                |
| D211 | 52  | COLON          | 0      | COLON BLINKING | 1 | COLON STOP     |   |                |   |                |
| D212 | 53  | TIME DISPLAY   |        | 12 HOUR        |   | 24 HOUR        |   |                |   |                |
| D213 | 54  | AM STEREO      | 0      | AM STEREO      | 1 | AM MONO        |   |                |   |                |
| D214 | 55  | INITIAL VOLUME | 0      | VOLUME MEMORY  | 1 | VOLUME DISPLAY | 0 | VOLUME DISPLAY | 1 | VOLUME DISPLAY |
| D215 | 56  | INITIAL VOLUME | 0      | VOLUME MEMORY  | 1 | VOLUME DISPLAY | 0 | VOLUME DISPLAY | 1 | VOLUME DISPLAY |


CN802  
TO CD PCB




CN803  
TO CD PCB



CN201  
TO MAIN PCB



CN202  
TO MAIN PCB



CN203  
TO MAIN PCB

