


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O


C BOARD WAVEFORMS



C BOARD * MARK LIST

CN703	4P	KV-T29CF1
V901	M68KZ171X	

Note: The parts indicated as "*" in this circuit diagram are not listed here, as they are not used for this model.



PRINTED WIRING BOARDS **C** [RGB OUT] **F1** [POWER] **VM** [VM OUT, ROTATION, V-PIN DF CIRCUIT]

