


GSI Lumonics

MiniSAX User Manual



Component Products Group
39 Manning Road
Billerica, Massachusetts 01821

GSIL P/N: 176-25016
Rev E
©GSI Lumonics 2004

TABLE OF CONTENTS

1	IMPORTANT INFORMATION	1
1.1	ESD WARNING.....	1
1.2	WARRANTY INFORMATION	1
1.3	CUSTOMER SUPPORT.....	2
2	INTRODUCTION	3
3	SPECIFICATIONS	4
4	CONNECTIONS	7
4.1	POWER SUPPLY	7
4.2	CONTROL SIGNAL INTERFACE.....	8
4.2.1	<i>Command Input</i>	9
4.2.2	<i>Temperature Status</i>	9
4.2.3	<i>Servo Enable</i>	9
4.2.4	<i>Servo Ready</i>	9
4.2.5	<i>Scanner Position</i>	9
4.3	SCANNER CONNECTIONS.....	9
4.4	TEST INTERFACE CONNECTOR	10
5	PROTECTION CIRCUITRY	11
5.1	FAULT DETECTION.....	11
5.2	FUSES.....	11
6	THERMAL CONTROL MODULE	12
6.1	INSTALLATION	12
6.2	INDICATOR LIGHTS	12
6.3	TEMPERATURE SET POINT.....	12
6.4	TEMPERATURE STATUS FLAG	12
7	TEST INTERFACE BOARD	13
8	SWITCH SETTINGS	14
9	MOUNTING SCANNERS	16
9.1	TEMPERATURE REGULATION	16
9.1.1	<i>Thermal Analysis</i>	17
9.1.2	<i>Heatsink Design</i>	19
9.2	HEATSINKING.....	19
9.2.1	<i>The Problems with Heat</i>	19
9.2.2	<i>Analyzing Heatsinking Requirements</i>	19
9.2.3	<i>Power Dissipation</i>	19

9.2.4	Thermal Runaway	20
9.2.5	Scanner Mounting	20
10	TUNING STRATEGIES	22
10.1	SERVO ARCHITECTURE	22
10.2	NOTCH FILTER	23
10.3	ACCURACY AND HIGH SPEED TUNING	23
10.4	LARGE-SIGNAL AND SMALL-SIGNAL WAVEFORMS	24
10.5	STEP WAVEFORMS	25
10.6	RASTER WAVEFORMS	26
10.7	VECTOR WAVEFORMS	26
11	FACTORY TUNING	27
12	TUNING INSTRUCTIONS	28
12.1	EQUIPMENT	28
12.2	DO'S AND DON'TS	28
12.3	ROUGH TUNING	28
12.4	NOTCH FILTER ADJUSTMENT	30
12.5	GAIN AND OFFSET ADJUSTMENT	30
12.6	SERVO ADJUSTMENT, SPEED-OPTIMIZED	31
12.7	SERVO ADJUSTMENT, ACCURACY-OPTIMIZED	32
13	TROUBLESHOOTING (MOST COMMON CAUSES OF MALFUNCTION)	34